CENTRAL

SOUTH

Station Location & ID

Yard Location

Maintenance District Boundary

Maintenance Zone Boundary

Zone Station Boundary

ZONE 1 (LAUREL)

ZONE 2 (BRIDGEVILLE)

ZONE 3 (ELLENDALE)

ZONE 4 (GEORGETOWN)

ZONE 5 (SELBYVILLE)

South District H.Q.

DELAWARE BAY

ATLANTIC OCEAN

MARYLAND

KENT COUNTY

SUSSEX COUNTY

CAPE MAY - LEWES FERRY (TOLL)

CAPE MAY - 16 MILES

Printed in U.S.A.

© DELDOT 2009