


LOOP DETECTOR LEAD-IN WIRE INSTALLATION



NOTES:

- 1). ALL SAWCUTS SHALL BE A DEPTH OF $3\frac{1}{2}$ " ON ALL SURFACES.
- 2). CONTRACTOR SHALL INSTALL LEAD-IN WIRE IN THE MOST DIRECT ROUTE TO THE JUNCTION WELL USING THE CLOSEST CONCRETE CURB JOINT.
- 3). ALL SAWCUTS SHALL BE SEALED WITH AN APPROVED LOOP DETECTOR SEALANT.
- 4). CONTRACTOR SHALL CORE AT FULL DEPTH OF SAWCUT, 3 $\frac{1}{2}$ ".
- 5). CONTRACTOR SHALL INSTALL DETECTABLE WARNING TAPE IN TRENCH FOR LEAD-IN CONDUIT.

LOOP DETECTOR LEAD-IN WIRE INSTALLATION

